

# Type YFV-1 Foot Valve

When installed on the pump inlet side of an underground water tank, this product is suitable for preventing the backward flow of fluid.



### Specifications

| Applicable fluid         |            | Water              |  |  |
|--------------------------|------------|--------------------|--|--|
| Maximum running pressure |            | Maximum 14kgf/cm²g |  |  |
| Fluid temperature        |            | 80°C below         |  |  |
| Leakage allowance        |            | 0                  |  |  |
| End connection           |            | KS 10K RF FLANGE   |  |  |
| Materials                | Body       | GC200              |  |  |
|                          | Disc, seat | NBR, BC6           |  |  |
|                          | Screen     | STS                |  |  |
| Hydraulic test pressure  |            | 20kgf/cm²g         |  |  |

▶ Valves for 20 kgf/cm²g are available by made-to-orders.

# **■** Dimensions


(mm)

|          |     |     |     |      | (           |
|----------|-----|-----|-----|------|-------------|
| Size     | E   | H1  | H2  | Н3   | Weight (kg) |
| 40(1½")  | 120 | 95  | 162 | 324  | 9.2         |
| 50(2")   | 135 | 100 | 183 | 366  | 11.7        |
| 65(2½")  | 145 | 100 | 200 | 400  | 14.2        |
| 80(3")   | 150 | 110 | 210 | 420  | 17.8        |
| 100(4")  | 160 | 120 | 217 | 434  | 23.6        |
| 125(5")  | 190 | 125 | 255 | 510  | 36.5        |
| 150(6")  | 200 | 135 | 280 | 560  | 47.3        |
| 200(8")  | 235 | 210 | 416 | 832  | 88.5        |
| 250(10") | 275 | 260 | 560 | 1120 | 106         |

#### ■ Notes for installation in a pump line

- Using the type YHL-1 hammerless check valve, instead of a swing-type valve, on the outlet side of a pump, will prevent a water hammer and protect the pump and pipeline.
- · Since the disc of the hammerless check valve and the foot valve is made of NBR, a perfect sealing is maintained. In particular, there is little pressure loss, resulting in less electricity consumption.
- Install a flexible tube on the upper part of the check valve to prevent pipeline vibration resulting from pump vibration.
- The primary pressure control valve (relief valve) maintains a constant pressure level on the pump outlet side, according to the set pressure.
- Install a strainer on the inlet side of the pump to protect facilities in the pipeline and the pump.

■ Dimensional drawing



# ■ Application Diagram (Example)

